



Roller Drop Bar

The Omega Roller Drop Bar is utilized to activate the release trigger of the releasable rope socket (RRS) and allow recovery of the wireline, drop bar, and the upper section of the RRS from the wellbore.

The drop bar is available to suit all wire sizes and can be fitted with rollers based on tubing size and any restrictions in the wellbore. The roller drop bar is utilized where deviation affects the use of a standard drop bar.

Technical Specifications

omega-intervention.com

Roller Drop Bar

Item	Max OD	Fish Neck Size.	Length	Wheel OD**
1	1-1/2"	1.375"	3ft	N/A
2	1-1/2"	1.375"	3ft	1.800"
3	1-1/2"	1.375"	5ft	N/A
4	1-1/2"	1.375"	5ft	1.800"
5	1-7/8"	1.750"	3ft	N/A
6	1-7/8"	1.750"	3ft	2.400"
7	1-7/8"	1.750"	5ft	N/A
8	1-7/8"	1.750"	5ft	2.400"

** Wheel OD should be specified at time of order



Features - Applications - Benefits

omega-intervention.com

Roller Drop Bar



FEATURES

- Extensive range of roller sizes available.

APPLICATIONS

- Activation of releasable rope socket.

BENEFITS

- Suitable for all standard slickline and braided wire sizes.

Omega Well Intervention Ltd, Omega House, Kirkhill Road, Kirkhill Industrial Estate, Dyce, Aberdeen, AB21 0GQ
Tel: +44 (0)1224 772744, Email: info@omega-intervention.com
www.omega-intervention.com

ED-012 R2.2


Omega
Well Intervention